



Wireless Earphone



1. Main to Sub PCB

Narrow Hybrid
Depth : 1.7mm



[BM28 Series](#)

2. RF Switch


Micro Coaxial
Switch
Height : 0.85mm



[MS-180 Series](#)

3. Battery

Narrow Battery
Depth : 1.5mm



[BM29 Series](#)

Narrow Hybrid
Pitch : 0.3mm



[BM55 Series](#)

4. USB Type-C

USB Type-C
6A Max.



[CX Series](#)

5. Speaker

One Action,
Simple and Easy
Pitch : 0.25mm



[OneAction FHTM
FH82 Series](#)

6. Speaker & IR Sensor

Low Profile ZIF
Height : 0.5mm



[FHTM
FH64 Series](#)

7. Touch Sensor, Microphone, Antenna to Main PCB

Low Profile ZIF
Height : 0.5mm



[FHTM
FH64 Series](#)

Wireless Earphone Block Diagram

